

CHANGING LAMPS & REMOVING SIGN FACES

Remove the aluminum retainer (L shaped metal) on one end of the sign. These are fastened to the sign frame by aluminum screws.

Slide out the entire sign face. This will reveal the fluorescent lamps.


Remove the lamps by firmly grasping the tube with two hands and pushing gently toward the end with the spring loaded socket. The lamp should pull out on the opposite end and then you can remove from the other end.

Replace lamp with equivalent high output lamp. Lamp information is printed on the end of each lamp. Call Cornerstone Companies at 800-456-9371 if assistance is required.

Replace both the face and the retainer. Screw retainer back into position.



Standard lamps
CWHO T-12 pin types



www.marqueesign.com